

FAST FORTH V3.2 RESUMED

<https://framagit.org/Jean-Mi/FAST-FORTH>

Words in braces {} are **MARKER** words.

FORTH vocabulary

Words with hyperlink are ANSI compliant. The others are detailed below.

COLD	WARM	WIPE	RST_HERE	PWR_HERE	RST_STATE	PWR_STATE	BEGIN
DOES>	CREATE	[]	[]	IMMEDIATE	POSTPONE	[]	[]
\	ALLOT	[']	ABORT"	ABORT	QUIT	EVALUATE	COUNT
LITERAL	U.	SIGN	>NUMBER	FIND	WORD	"	S"
+KEY	CR	TYPE	HOLD	#>	#S	#	<#
			NOECHO	ECHO	EMIT	ACCEPT	

COLD Software reset
WARM primary DEFERred word, performs a hot start
WIPE resets the program memory to its original state.
RST_HERE defines the boundary of the program memory protected against COLD or hardware reset.
PWR_HERE defines the boundary of the program memory protected against ON/OFF and against any error occurring.
RST_STATE remove all words defined after RST_HERE
PWR_STATE remove all words defined after PWR_HERE
NOECHO stop display on output
ECHO start display on output

ASSEMBLER vocabulary

?GOTO	GOTO	FW3	FW2	FW1	BW3	BW2	BW1
REPEAT	WHILE	AGAIN	UNTIL	ELSE	THEN	IF	0=
0<>	U>=	U<	0<	0>=	S<	S>=	RRUM
RLAM	RRAM	RRCM	POPM	PUSHM	CALL	PUSH.B	PUSH
SXT	RRA.B	RRA	SWPB	RRC.B	RRC	AND.B	AND
XOR.B	XOR	BIS.B	BIS	BIC.B	BIC	BIT.B	BIT
DADD.B	DADD	CMP.B	CMP	SUB.B	SUB	SUBC.B	SUBC
ADDC.B	ADDC	ADD.B	ADD	MOV.B	MOV	RETI	LO2HI
COLON	ENDASM	ENDCODE					

ASM [CODE](#) [HI2LO](#) <-- added to FORTH vocabulary

ASM <word> creates an assembler word as [CODE](#) but which is not interpretable by FORTH (because use of [CALL ... RET](#)). this defined <word> must be ended with [ENDASM](#).

CODE <word> creates a FORTH words, ready to be written in assembly. This word must be terminated with [ENDCODE](#) unless using [COLON](#) or [LO2HI](#).

HI2LO used to switch from a high level (FORTH) to low level (assembler) modes.

?GOTO used after a conditional (0=,0<>,U>=, U<,0<,S<,S>=) to branch to a label FwX or BwX
GOTO used as unconditional branch to a label FwX or BwX

FW3 FORWARD branch destination n*3 (single use)
FW2 FORWARD branch destination n*2 (single use)
FW1 FORWARD branch destination n*1 (single use)

BW3 BACKWARD branch destination n*3
BW2 BACKWARD branch destination n*2
BW1 BACKWARD branch destination n*1

REPEAT assembler version of the FORTH word [REPEAT](#) (unconditional branch)
WHILE assembler version of the FORTH word [WHILE](#) (conditional branch preceded by 0=,0<>,U>=, U<,0>=, S<,S>=)
AGAIN assembler version of the FORTH word [AGAIN](#) (unconditional branch)
UNTIL assembler version of the FORTH word [UNTIL](#) (conditional branch preceded by 0=,0<>,U>=, U<,0>=, S<,S>=)
ELSE assembler version of the FORTH word [ELSE](#) (unconditional branch)
THEN assembler version of the FORTH word [THEN](#) ends IF or IF ELSE statements
IF assembler version of the FORTH word [IF](#) (conditional branch preceded by 0=,0<>,U>=, U<,0>=, S<,S>=)

LO2HI switches between low level and high level interpretation mode (counterpart of [HI2LO](#)), without saving IP.
COLON pushes IP then performs [LO2HI](#), used as: [CODE <word> ... assembly code ... COLON ... FORTH words ... ;](#)
ENDASM to end an ASM definition
ENDCODE to end a CODE definition

To better understand the use of the assembler I refer you to [\MSP430-FORTH\ANS_COMP.f](#) and [\MSP430-FORTH\RC5toLCD.f](#)

Extended ASSEMBLER words

RPT	PUSHX.B	PUSHX.A	PUSHX	SCTX.A	SCTX	RRAX.B	RRAX.A
RRAX	SWPBX.A	SWPBX	RRUX.B	RRUX.A	RRUX	RRCX.B	RRCX.A
RRCX	ANDX.B	ANDX.A	ANDX	XORX.B	XORX.A	XORX	BISX.B
BISX.A	BISX	BICX.B	BICX.A	BICX	BITX.B	BITX.A	BITX
DADDX.B	DADDX.A	DADDX	CMPX.B	CMPX.A	CMPX	SUBX.B	SUBX.A
SUBX	SUBCX.B	SUBCX.A	SUBCX	ADDCX.B	ADDCX.A	ADDCX	ADDCX.A
ADDX.A	ADDX	MOVX.B	MOVX.A	MOVX	CALLA	SUBA	ADDA
CMPA	MOVA						

RPT #n|RPT Rn used with [Reg](#) and [Reg,Reg](#) extended instructions, to repeat them 1 to 16 times.
Example: [RPT #12 ADDX R1,R1](#) will shift left 12 times [R1](#)

Here are adds-on to be compiled

CONDCOMP

[DEFINED] [UNDEFINED] [IF] [ELSE] [THEN]

VOCABULARY

DEFINITIONS ONLY PREVIOUS ALSO ASSEMBLER FORTH VOCABULARY

FORTH replace first words set in CONTEXT by the words set FORTH
ASSEMBLER replace first words set in CONTEXT by the words set ASSEMBLER
VOCABULARY VOCABULARY TRUC creates a new words set called TRUC

SD_CARD_LOADER

LOAD" LOAD" SD_TEST.4TH" compiles/executes file SD_TEST.4TH from current_directory.
LOAD" \MISC\TEST_ASM.4TH" compiles/executes file TEST_ASM.4TH from current_directory\MISC\
LOAD" \MISC" changes to directory \MISC
LOAD" ..\" changes to parent directory
LOAD" \" changes to root directory

SD_CARD_READ_WRITE

TERM2SD" SD_EMIT WRITE READ CLOSE DEL" WRITE" READ"

TERM2SD" TERM2SD" SD_TEST.4TH" copy input file to SD_CARD (use CopySourceFileToTarget_SD_Card.bat to do)
WRITE write sequentially BUFFER content to a sector
READ read sequentially a sector to BUFFER
CLOSE close last opened file.
DEL" SD_TEST.4TH" remove this file from SD_CARD.
WRITE" TRUC" open or create TRUC file ready to write to the end of this file
READ" TRUC" open TRUC and load its first sector in BUFFER

see SD_TEST.f

NONAME_ADD-ON

:NONAME CODENNM
CODENNM assembly counterpart of :NONAME

BOOTLOADER

BOOT

QUIT becomes a primary DEFERred word

BOOT the input: ' BOOT IS QUIT allow downloading BOOT.4th from SD CARD during the process RESET.
to cancel the bootstrap: ' QUIT >BODY IS QUIT

Below, adds-on that can be compiled in kernel or loaded later

ANS_COMPLEMENT

PAD	>IN	BASE	STATE	SOURCE	EXECUTE	HERE	RECURSE
+LOOP	LOOP	I	DO	REPEAT	WHILE	AGAIN	UNTIL
THEN	ELSE	IF	>BODY	LEAVE	UNLOOP	SPACES	SPACE
BL	J	.((DECIMAL	HEX	FILL	[CHAR]
CHAR	+!	MIN	MAX	Z/	2*	RSHIFT	LSHIFT
>	<	INVERT	XOR	OR	AND	C.	C!
C@	NIP	2OVER	ZSWAP	2DROP	2DUP	ZVALUE	Z!
2@	R@	ROT	OVER	CELL+	CELLS	CHAR+	CHARS
ALIGN	ALIGNED	*/	*/MOD	MOD	/	/MOD	*
1+	+	ABS	NEGATE	FM/MOD	SM/REM	UM/MOD	M*
UM*	S>D	TO	VALUE	CONSTANT	VARIABLE	U<	=
0<	0=	!	@	1-	VARIABLE	DEPTH	R>
>R	SWAP	DROP	?DUP	DUP	EXIT	MOVE	{ANS_COMP}

{ANS_COMP} do nothing if compiled in core, else remove all from {ANS_COMP}.

UTILITY

DUMP U.R WORDS ? .RS .S {TOOLS}

U.R u z -- display unsigned number u with size z
.RS display Return Stack content
{TOOLS} do nothing if compiled in core, else remove all from {TOOLS}

SD_TOOLS

DIR FAT CLUSTER SECTOR {SD_TOOLS}

DIR dump first sector of current directory
FAT dump first sector of FAT1
CLUSTER .123 CLUSTER displays first sector of cluster 123
SECTOR .123456789 SECTOR displays sector 123456789
{SD_TOOLS} do nothing if compiled in core, else remove all from {SD_TOOLS}.

FIXPOINT you must uncomment the FIXPOINT_INPUT switch before use this add-on.

2CONSTANT S>F F. F* F#S F/ F- F+
HOLDS {FIXPOINT}

S>F u/n -- Q10 Qhi convert u/n in a Q15.16 value
F. display a Q15.16 value
F* Q15.16 multiplication
F#S Q10 Qhi u -- Qhi 0 convert fractionnal part of a Q15.16 value displaying u digits
F/ Q15.16 division
F- Q15.16 soustraction
F+ Q15.16 addition
{FIXPOINT} do nothing if compiled in core, else remove all from {FIXPOINT}.

build your FastForth local copy

download <https://framagit.org/Jean-Mi/FAST-FORTH/tree/master>

once you have unzipped it into your folder, share it (with you) and notice its network path. Then right clic on the root of your notepad to create a network drive by recopying this network path (change backslashes \ to slashes /); then set drive letter as you want.

In explorer you should obtain that:

```
drive:\
  \ForthMSP430FR.asm          forthMSP430FR.asm files ready to build
  \ForthMSP430FR_ASM.asm      main FASTFORTH program
  \ForthMSP430FR_CONDCOMP.asm assembler
  \ForthMSP430FR_HALFDUPLEX.asm init SD_CARD (FAT16/32)
  \ForthMSP430FR_SD_ACCEPT.asm half duplex terminal
  \ForthMSP430FR_SD_LOAD.asm  conditionnal compilation
  \ForthMSP430FR_SD_Init.asm  init SD_CARD (FAT16/32)
  \ForthMSP430FR_SD_Load.asm  load source files from SD_CARD
  \ForthMSP430FR_SD_Level1.asm SPI routines + Read / write sector
  \ForthMSP430FR_SD_RW.asm    read create write del SD_CARD files + file copy from terminal to SD_CARD
  \ScITEDirectories.properties copy of \config\scite\AS_MSP430\ScITEDirectories.properties

drive:\ADD-ON\
  \ANS_COMPLEMENT.asm        FASTFORTH OPTIONAL KERNEL ADD-ON switches (not erasable version)
  \FIXPOINT.asm              set of complementary words to pass CORETEST.4TH
  \SD_TOOLS.asm               adds Q15.16 numbers interpretation
  \UTILITY.asm                adds some trivial words to display sectors content
                               adds WORDS, DUMP, ? .S

drive:\binaries\
  \prog(.bat)                 files.txt|files.HEX ready for drag'n drop to prog.bat
                               used to program targets.

drive:\config\
  \config\                    some files.bat
  \config\                    Teraterm macros files.ttl
  \config\                    SCITE configuration files.properties

drive:\inc\
  \MSP430FRxxxx.inc          MACRO Assembler files.inc, files.asm, GEMA preprocessor files.pat
  \MSP430FRxxxx.asm          device configuration for AS assembler
  \MSP_EXP430FRxxxx.asm      device code for AS assembler
  \FastForthREGtoTI.pat      target configuration for AS assembler
  \tiREGtoFastForth.pat      converts FORTH symbolic registers names to TI Rx registers
  \MSP430FRxxxx.pat          converts TI Rx registers to FORTH symbolic registers names
  \MSP_EXP430FRxxxx.pat      device configuration for gema preprocessor
  \MSP_EXP430FRxxxx.pat      target configuration for gema preprocessor

drive:\MSP430-FORTH\
  \PreprocessSourceFile.bat   FORTH generic_source_files.f and targeted_source_files.4th
  \SendSourceFileToTarget.bat (link)
  \CopySourceFileToTarget_SD_Card.bat (link)
  \*.f                         source files which must be preprocessed before downloading
  \*.4th                       source files ready to download to any target
  \LAST.4TH                    last source file issued by preprocessor and downloaded to your target
  \ANS_COMP.f                  same as ANS_COMP.asm, (but erasable)
  \BOOT.f                      performs bootstrap
  \CHNGBAUD.f                  allows you to change terminal baudrate
  \CORETEST.4TH                ANS core tests
  \CORDIC.f                    for aficionadados
  \FIXPOINT.f                  same as FIXPOINT.asm, (but erasable)
  \FF_SPECS.f                  shows all specificities of FAST-FORTH compiled on your target
  \RTC.f                       set time and date with embedded RTC (MSP430FR5xxx, FR6xxx)
  \RC5toLCD.f                  multitasking example
  \SD_test.f                   tests for SD_CARD driver
  \SD_TOOLS.f                  same as SD_TOOLS.asm, (but erasable)
  \TESTASM.f                   some tests for embedded assembler
  \TESTXASM.f                  some tests for embedded extended assembler
  \UTILITY.f                   same as UTILITY.asm, (but erasable)

drive:\prog\
  \sciteGlobal.properties + files.html

SCITE configuration files:
drive:\config\ScITEDirectories.properties scite directory config file
  \asm.properties               configuration for *.inc,*.asm files
  \forth.properties            configuration for *.f,*.4th files
  \fortran.properties          configuration for *.pat files

drive:\config\SendFile.ttl
  \SendToSD.ttl                TERATERM macro file to send source file to FASTFORTH
  \build(.bat)                 TERATERM macro file to send source file to embedded SD_CARD
  \prog(.bat)                  called by scite to build target.txt program
  \CopyTo_SD_Card(.bat)        to flash target with target.txt file
  \SendSource(.bat)            to copy in your MSP430-FORTH
  \Preprocess(.bat)            to send file to FASTFORTH
  \CopySourceFileToTarget_SD_Card.bat to convert generic .f file to specific .4th file
  \SendSourceFileToTarget.bat to copy in any user folder for drag'n drop use
  \PreprocessSourceFile.bat    to copy in any user folder for drag'n drop use
  \SelectTarget.bat            to copy in any user folder for drag'n drop use
                               called by them three to select target
```

Note: all actions made from ScITE editor are processed via bat/bash files.
So you can easily use your preferred editor by reuse them.

Note: all actions (flashing target, downloading files) can be made by using bat files directly, i.e. without use of ScITE editor.

The next is to download IDE (WINDOWS):

First get TI's programs

go here: <http://www.ti.com/> and registers you to enable MSP430Flasher downloading:

<http://www.ti.com/tool/msp430-flasher?DCMP=MSP430&HQS=Other+OT+msp430flasher>

and

http://software-dl.ti.com/msp430/msp430_public_sw/mcu/msp430/MSP430_FET_Drivers/latest/index_FDS.html

install in the suggested directory,
then copy MSP430Flasher.exe and MSP430.dll to **drive:\prog**

download and install teraterm: <https://osdn.net/projects/ttssh2/releases/>

<https://sourceforge.net/projects/gema/files/latest/download>

unzip in **drive:\prog**

download <http://www.scintilla.org/Sc41x.exe> to **drive:\prog**

then rename Sc41x.exe to scite.exe

<http://john.ccac.rwth-aachen.de:8000/ftp/as/precompiled/i386-unknown-win32/aswcurr.zip>

unzip in **drive:\prog**

<https://sourceforge.net/projects/srecord/files/latest/download>

unzip in **drive:\prog**

In explorer you should obtain that (minimum requested programs):

```
drive:\prog\  SciTEGlobal.properties
              gema.exe
              asw.exe
              P2hex.exe
              as.msg
              cmdarg.msg
              ioerrr.msg
              P2hex.msg
              tools.msg
              MSP430Flasher.exe
              MSP430.dll
              srec_cat.exe
              scITE.exe
```

Next we need to change the drive letter in hard links below:

drive:\binaries\prog.bat

```
drive:\MSP430-FORTH\SendSourceFileToTarget.bat
                  CopySourceFileToTarget_SD_Card.bat
                  PreprocessSourceFile.bat
```

to do, right clic on them
select "properties"
set your drive letter in "target"

The last step is ask windows to associate scite editor with file types:

right clic on a **.asm** file,
select "open with",
select "other application" then select: **drive:\prog\scite.exe**

repeat for **.inc, .lst, .f, .4th, .pat, .properties, .TTL** files.

IT's done ! See **forthMSP430FRxxxx.asm** to configure TeraTerm

IDE for linux UBUNTU / MINT

First search from ti.com:

http://software-dl.ti.com/msp430/msp430_public_sw/mcu/msp430/MSP430Flasher/latest/index_FDS.html

untar in a home folder then:

```
open MSPFlasher-1.3.16-linux-x64-installer.run
  install in MSP430Flasher (under home)
```

```
open a terminal in MSP430Flasher/Drivers:
  sudo ./msp430uif_install.sh
```

```
copy MSP430Flasher/MSP430Flasher to /usr/local/bin/MSP430Flasher
copy MSP430Flasher/libmsp430.so to /usr/local/lib/MSP430Flasher/libmsp430.so
```

```
open an editor as superuser in /etc/ld.so.conf.d/
  write on first line (of new file): /usr/local/lib/msp430flasher/
  save this new file as libmsp430.conf
then in a terminal: sudo /sbin/ldconfig
```

install the package srecord

install the package scite

```
as super user, edit /etc/scite/SciTEGlobal.properties
uncomment (line 18): position.maximize=1
uncomment (line 257): properties.directory.enable=1
add line 7: PLAT_WIN=0
add line 8: PLAT_GTK=1
save file
```

```
at the end of your ~/.profile file, add these two lines:
FF="/the_root_of_your_FastForth_local_copy"
export FF
```

<https://sourceforge.net/projects/gema/files/gema/gema-1.4-RC/gema-1.4RC-src.tgz/download>

```
untar in a home folder then:
make (ignore warnings)
sudo make install (ignore warnings)
make clean
result in: /usr/local/bin/gema
```

http://john.ccac.rwth-aachen.de:8000/ftp/as/source/c_version/as1-current.tar.gz

```
untar in a home folder then:
copy /Makefile.def-samples/Makefile.def-i386-unknown-linux2.x,x to ../Makefile.def
edit this Makefile.def to remove "-march=i586" option from line 7 (if any)
make
make test
sudo make install
make clean
result: as1 files are in /usr/local
```

install minicom package

```
sudo gpasswd --add ${USER} dialout
```

```
copy /config/msp430/.minirc.dfl in your home directory.
```

```
In /inc/RemoveComments.pat, deselect windows part, select linux part.
```

```
-----
With scite editor you can
- assemble FastForth then download it to eZFET target,
- edit your source files
- preprocess file.f to file.4th
```

```
With minicom you can send a file.4th to your target via dev/ttyUSB0, up to 4Mbauds:
CTRL_A + Y to send a file
```